




1




2




3



4




5




6




PPL IMP 6729Ba




P3
(Standard pump or valve...)



P2
(Standard pump, PWM pump, Booster pump or valve)




P1
(Standard pump or PWM pump)




Power supply

230 VAC
50Hz




GDS1


Grundfos
VFS flow
sensor



Grundfos
RFS
Pressure
sensor



GDS2
(Grundfos RPS
pressure sensor)



T1 (collector1 sensor)

T2 (tank1 sensor)

T3 (Extra sensor)

T4 (Extra sensor, tank2 sensor or collector2)

T5 (Collector return)

T6/PF

(Impulse flow sensor)